


CS-700 フィールドコーヒーブリューウー

この度は、スノーピーク製品をお買い上げいただき、誠にありがとうございます。本製品は水出しコーヒーポトルです。安全にご使用いただくためにも下記の取扱説明書をよく読んでからご使用ください。また、読み終わったら大切に保管してください。説明内容で理解出来ない点及び製品に不具合が確認された際には直ちに使用を中止し、ご購入いただきました販売店様もしくは弊社ユーザーサービスまでお問い合わせください。

セット内容(各部の名称)



スペック

- セット内容:ボトル本体、キャップ、ストレーナー、パッキン
- 材質:ボトル本体／飽和ポリエチル樹脂(トライアン)、キャップ／ポリプロピレン、ストレーナー／ステンレス、パッキン／シリコーンゴム
- サイズ:φ100×257.5(h)mm
- 重量:435g
- 適正容量:700mL
- 満水容量:900mL ※ストレーナーを組付けない場合

交換用パッキンの品番(名称)
XCS-700-02(CS-700 パッキン 2pcsセット)

家庭用品品質表示による表示


	原料樹脂	耐熱温度	耐冷温度
ボトル本体	飽和ポリエチル樹脂	100°C	0°C
キャップ	ポリプロピレン	100°C	0°C
パッキン	シリコーンゴム	180°C	0°C

取扱い上の注意

- 火のそばに置かないでください。
- 柑橘類の皮に含まれるテルペニによりボトル本体が変質するおそれがあります。柑橘類を使用したお飲み物には使用しないでください。
- 冷凍庫に入れて使用すると破裂するおそれがあります。
- 電子レンジでは使用しないでください。
- 熱いお飲み物を入れた際は、必ずキャップを外し、さましてからキャップをしてください。

■ストレーナーのセット方法


キャップを取り外し、①ストレーナーの突起をキャップの溝に合わせ、②回転・半回転させることで取り付け・取り外しができます。ストレーナーが取り付けられた際はカチッと鳴ります。また、ストレーナーのボトムキャップはネジ式で開閉することができます。抽出する際はボトムキャップがしっかりと締まっていることを確認してください。



■水出しコーヒーの作り方

- ①水をMAX容量線(700mL)の目盛りまで入れます。
- ②キャップからストレーナーを取り外し、ストレーナーにアイスコーヒー用(深煎り)の粉をコーヒー粉容量線(最大55g)まで入れます。粉は中挽きを推奨します。
- ③キャップにストレーナーを取り付けた後、ボトル本体にキャップを時計回りにカチッという感覚があるまで締めます。
- ※使用する際は必ずパッキンがはまっていることを確認してください。

△注意 本製品を指定された位置以上に締め付けると止水機能が働かなくなり、水が漏れるおそれがあります(右図)。締め付けた後は、水が漏れないことを確認した上でご使用ください。




使用方法

④コーヒー粉全体がしっかりと浸るように、本体を5回程度ゆっくり傾けて馴染ませてください。


*本体を振らないでください。

⑤冷蔵庫で約8時間抽出します。抽出時間は目安ですので好みによって調整してください。



⑥注ぐ際はキャップをカチッと鳴るまで90°回転させ、マグカップに注ぎ入れます。

△注意 お作りになった水出しコーヒーはお早めにお召し上がりください。冷蔵庫で保管されている間雑菌が増殖し変質するおそれがあります。



⑦お好みの抽出濃度になりましたら、キャップからストレーナーを取り外してください。

■水出しコーヒーをおいしく楽しむためのポイント

- 出来上がりの味を大きく左右しますので、カルキ臭の少ない水をご用意ください。
- ミネラルウォーターをご使用の際は軟水タイプをおすすめします。
- 温めて召し上がる際は沸騰させないようにご注意ください。成分が酸化し、風味が損なわれます。
- 必ず冷蔵保存し、早めにお召し上がりください。日がたつと酸化が進みます。
- 出来上がりの量はご使用いただく粉の種類により若干異なる場合があります。

■抽出した水出しコーヒーを持ち運ぶ場合

キャップからストレーナーを取り外し、キャップをしっかりと締めてから持ち運んでください。
※ストレーナーを取り付けたままの場合、コーヒーの粉が攪拌され風味が損なわれます。
フタにコーヒーの粉が付着している場合は、洗い流してください

メンテナンス

●長期間ご使用しなかった製品を再度お使いになる際は、本製品を点検し各部に異常がないことを確認してください。異常が発見された場合は、直ちに使用を中止しお買い求めいただいた販売店様、または弊社ユ

ーザーサービスに点検または修理を依頼してください。

●普段のお手入れには柔らかいスポンジに中性洗剤をつけて洗ってください。クレンザー、金属製のたわしや磨き粉は使用しないでください。

●ストレーナーのボトムキャップを取り外すと洗浄しやすくなります。

●ご使用後は汚れを早めに落とし、十分に乾燥させて保管してください。

●汚れがひどいときは「家庭用漂白剤」を薄めてご使用ください。その際「家庭用漂白剤」の取扱注意事項を必ずお守りください。漂白剤は十分に水洗いしてください。

●プラスチック製品、金属製ストレーナーは「家庭用漂白剤」に長時間漬け置きしますと耐久性が低下しますので、短時間の使用としてください。

●本製品には食器洗浄機や乾燥機を使用しないでください。本体の変形や変色の原因となります。

品質保証について

お買い求めいただきました製品は万全を期していますが、万一不備な点がございましたら、お買い求めいただいた販売店様もしくは弊社または各製品に記載された連絡先にご相談ください。製造上の欠陥が原因の場合は無償で修理または交換させていただきます。その他の場合は適切な価格で修理させていただきます。修理、交換の判断は弊社の裁量によるものとさせていただきます。また、以下の場合は修理できない場合もありますので予めご了承ください。

1. 素材の経年劣化による損害など商品の寿命

2. 改造および粗雑な取扱いによる故障

3. 取扱説明書で禁止されている取扱いによる故障

4. 不測の事故による商品の故障

5. その他製造上の欠陥以外による製品の故障

6. ゴミやさびによる故障

7. 分解したことによる不具合の発生または破損

8. 落下やその他の衝撃による部品の変形や破損による不具合

9. 摩擦によるバースの変化及びそれにによる故障

10. 他社製品との組み合わせによる故障

修理について

●本格的な修理が必要な場合は、お買い求めになった販売店様または弊社ユーザーサービスまでお問い合わせください。

●修理を依頼される場合は、必ず十分に乾燥させ、汚れをきれいに落としてください。

●修理品には修理箇所がはっきりと決まるように、必ずメモまたは荷札を付けてください。また破損時の状況をできるだけ詳しく書いたメモを添えてください。

●修理品の運賃並びに修理費については以下のように規定させていただきます。

1. 保証対象の場合は、往復運賃並びに修理費は弊社にて負担いたします。

2. 保証対象以外の場合は、往復運賃並びに修理費はお客様のご負担とさせていただきます。

不明な点やお気付きの点がございましたら、スノーピークユーザーサービス

販売店様または弊社ユーザーサービスまで

お問い合わせください。

0120-010-660 (9:00~17:00)

Email:userservice@snowpeak.co.jp

株式会社スノーピーク

〒955-0147 新潟県三条市中野原456

Tel.0256-46-5858 / Fax.0256-46-5860

www.snowpeak.co.jp

キャップ・ボトル本体:MADE IN JAPAN

パッキン:MADE IN VIETNAM


ストレーナー:MADE IN CHINA

この製品は日本で品質管理し、組み立てたものです。

CS-700 Field Coffee Brewer

Thank you for purchasing a Snow Peak product. This product is a cold brew coffee bottle. For safety, read the following instruction manual before use. After reading this manual, keep it in a safe place for future reference. Finally, if you find anything that you do not understand in the description or any problems with the product, please stop use immediately and contact the retailer or Snow Peak Customer Service.

Contents (Name of the Parts)



Instruction Manual

Safety Precautions: Before use, please read thoroughly to ensure safety and avoid

WARNING Misuse could result in serious injury or death.

● Before using the product, check each part for abnormalities. If there are abnormalities, take the product to the dealer or Snow Peak Customer Service for inspection or repair. ● This product is a bottle exclusively designed for coffee brewing. Do not use the product for any purpose other than its intended use. ● Store out of the reach of infants and small children. Also, if a child is using the product, do not allow them to handle it alone.

CAUTION Misuse could result in injury to the user and/or damage to property.

● Be sure to wash it thoroughly before using it for the first time. ● Never put the following items in this product. If the internal pressure increases, it may prevent the cap from being opened, the beverage may spray out, or the cap may break and scatter. In such cases, there is a risk of injury to the user or significant secondary damage. ① Dry ice, carbonated beverages ② milk, dairy beverages, fruit juices, and other beverages prone to spoilage ③ citrus fruits ● Do not use it with citrus beverages, as the terpenes in citrus peels may cause the bottle body to degrade. ● Do not use MCT oil in this product. Doing so may cause the bottle body to break. * MCT refers to medium-chain triglyceride oil, which is an ingredient of coconut oil, etc. ● Do not use plastic wrap. It may stick to the bottle body and become difficult to remove. ● The bottle body and cap, as well as the cap and strainer, are designed to fit together. Be sure to check that they are securely tightened. Otherwise, it may cause water leakage. ● Be sure to check that the cap gasket is attached correctly. Also check that the cap is securely fastened. (Otherwise, the contents may leak and stain objects.) ● The heat-resistant temperature of this bottle body is 100°C. Do not place this product near heat sources such as combustion lanterns, stoves, or heaters, or near open flames such as matches, candles, lighters, or cigarettes. In addition, never heat this product. Doing so may cause a personal injury or product damage. ● Do not apply excessive force to the strainer from the outside. Doing so may cause damage. ● Do not shake this product or subject it to excessive vibrations. The liquid inside may boil over. ● Do not put this product into a dishwasher or dryer. Doing so may cause deformation or discoloration of the main body. ● Be sure not to fill the beverage above the MAX capacity line. Doing so may cause the beverage to overflow when you attempt to tighten the cap. ● Before pouring a beverage, always check the bottle body spout position. Pouring in the incorrect direction may result in liquid spillage. Please exercise great care when using this product. ● Use this product in a stable location. Using the product in an unstable location may cause it to tip over or fall, leading to unexpected injuries or damage. ● When opening the cap, hold it horizontally and open it slowly without shaking. Otherwise, the contents may leak, which may lead to further damage. ● When carrying this product while it contains a beverage, be sure to turn the bottle body upside down to check that there are no leaks. ● When carrying this product while it contains a beverage, keep it in an upright orientation. Otherwise, the contents may leak, which may lead to further damage. ● When carrying this product by hand, do not hold the handle. Doing so may cause the product to fall or the contents to leak. ● Please note that repeated use of the bottle for coffee, tea, etc. may cause the interior or the gasket to become discolored. ● Due to its design, condensation will form on this product when cold beverages are poured into it due to the temperature difference with the surrounding air. This may cause other objects to become wet and lead to further damage, so pay attention when handling this product. ● If this product will not be used for a long period of time, loosen the cap to protect the gasket from deforming before storing the product. ● Do not freeze this product with a beverage inside it. Doing so may cause the beverage to expand and the bottle to burst. Also, if you are placing the product containing a hot beverage in a refrigerator, let the beverage cool down in advance. ● When pouring beverages into the product, the bottle body will become hot, so be careful not to get burned. ● When pouring hot beverages, please handle this product over a sink or similar surface, as it may be dangerous if it tips over. Also, when carrying the bottle body, let it cool down in advance. ● When you pour hot beverages in it, the bottle body may expand. This is due to changes in the air pressure inside the bottle. When adding a hot beverage, be sure to remove the cap and allow the contents to cool down before replacing the cap. ● When the temperature of the beverage inside the bottle drops, the internal pressure decreases, and it may become difficult to open the cap. If the cap does not open, pour hot water on the outside of the bottle to warm it up. This will make it easier to open the cap. ● If the coffee grounds or tea leaves are too fine, they may escape through the holes in the strainer. ● Do not subject the bottle to strong impacts such as tipping, dropping, or hitting. Doing so may cause damage or leakage.* This product is manufactured from Tritan material, which is highly impact-resistant, however, it may break if subjected to strong impacts. ● When storing the product horizontally, ensure that the cap and bottle body, as well as the cap and strainer, are securely fastened. ● Do not leave it in high-temperature areas, such as inside a car under the hot sun. ● Do not leave it for long periods with beverages, coffee grounds, or tea leaves inside. Doing so may cause spoilage or discoloration. ● Prolonged exposure to strong light, such as direct sunlight, may cause the product to deform. ● Do not leave the product wet (this may cause odor and stains). ● Be careful when making flavored coffee with a strong aroma, as the scent may transfer to the silicone rubber gasket. ● Attach the strainer to the cap before placing it in the bottle body. ● Please note that if you tilt the bottle body suddenly when pouring, liquid may come out of the spout forcefully.

Specifications

- Set Contents: Bottle body, Cap, Strainer, Gasket
- Material: Bottle body/Saturated polyester resin (Tritan), Cap/Polypropylene, Strainer/Stainless steel, Gasket/Silicone rubber
- Size: dia. 100x257.5(h)mm (3.9"x10.1")
- Weight: 435g (15.3oz)
- Suitable capacity: 700mL (23.7oz)
- Full capacity: 900mL (30.4oz) * Without the strainer installed

Part number (name) of replacement gasket

XCS-700-02 (CS-700 gasket 2pcs set)

Labeling in accordance with the Household Goods Quality Labeling

	Raw material resin	Heat resistance temperature	Cold resistance temperature
Bottle body	Saturated polyester resin	100°C (212°F)	0°C (32°F)
Cap	Polypropylene	100°C (212°F)	0°C (32°F)
Packing	Silicone rubber	180°C (356°F)	0°C (32°F)

Precautions regarding handling



- Do not place it near a fire.
- The terpenes in citrus peels may cause the bottle body to degrade. Do not use this product for citrus beverages.
- Using it in a freezer may cause an explosion.
- Do not use it in a microwave oven.
- When adding a hot beverage, be sure to remove the cap and allow the contents to cool down before replacing the cap.

Instructions for Use

How to set the strainer

Remove the cap, ①align the protrusion of the strainer with the groove of the cap, and ②rotate it half a turn to attach or remove it. You will hear a click when the strainer is securely attached. The bottom cap of the strainer can be opened and closed using a screw-on mechanism. When brewing, check that the bottom cap is tightly fastened.

click




Bottom cap

How to make cold brew coffee


- ① Add water up to the MAX capacity line (700mL (23.7oz)).
 - ② Remove the strainer from the cap and add the iced coffee (dark roast) powder into the strainer up to the coffee powder capacity line (up to 55g (0.12lb)). Medium ground coffee is recommended.
 - ③ After attaching the strainer to the cap, tighten the cap clockwise to the bottle body until you feel a click.
- * Please check that the gasket is in place before use.

CAUTION Tightening this product beyond the specified position may cause the seal to fail and result in leakage (see diagram). After tightening, check for any leaks before use.




- ④ Slowly tilt the main body about five times to thoroughly soak the coffee grounds.
- * Do not shake the main body.

- ⑤ Let it brew in a refrigerator for approximately eight hours. This brewing time period is a guideline, so adjust it to suit your preference.



- ⑥ When pouring, rotate the cap 90° (194°F) until it clicks, then pour the liquid into a mug.

CAUTION Please drink your cold brew coffee as soon as possible. Even if it is stored in a refrigerator, bacteria may grow and cause deterioration.



- ⑦ Once your desired brewing concentration has been reached, remove the strainer from the cap.

Tips for enjoying delicious cold brew coffee

- Use water with minimal chlorine odor, as it can significantly impact the flavor of the finished coffee.
- If using mineral water, we recommend opting for soft water.
- When warming up the coffee before drinking, take care not to bring it to a boil. This causes the components to oxidize, and diminishes the flavor.
- Always store the cold brew coffee in a refrigerator and enjoy it promptly. Oxidation will increase over time.
- The amount of coffee produced may vary slightly depending on the type of grounds used.

When transporting brewed cold brew coffee:

Remove the strainer from the cap and tighten the cap securely before carrying it.

- * If the strainer is attached, the coffee grounds will be stirred, compromising the flavor. If coffee grounds are stuck to the lid, rinse them off.

Maintenance

- When using the product after not using it for a long period of time, inspect it and make sure that there are no abnormalities in each part. If you find any abnormalities, stop using the product immediately and contact the retailer where you purchased the product or Snow Peak Customer Service for inspection or repairs.
- Regarding daily care of this product, wash using a soft sponge and mild detergent. Do not use cleansers, metal scrubbers, or polishing powders.
- Removing the bottom cap of the strainer makes it easier to clean.
- Remove any dirt as soon as possible after use and dry thoroughly before storing.
- If the product is heavily stained, use diluted household bleach. In that case, be sure to follow the handling instructions for the household bleach. Rinse the bleach thoroughly with water.
- Soaking plastic products and metal strainers in household bleach for long periods will reduce their durability, so limit exposure to a short time period.
- Do not put this product into a dishwasher or dryer. Doing so may cause deformation or discoloration of the main body.

Warranty

Snow Peak has taken all possible measures to ensure that every product is durable and functions correctly. If you find any product defects, please contact the retailer where you purchased the product or Snow Peak Customer Service. If there are apparent defects in the product's manufacturing, the defective product will be repaired or exchanged free of charge. In other cases, Snow Peak will repair the product for an appropriate fee. The decision to repair or replace the product will be at our discretion. Snow Peak will not repair the product for any damage that occurred due to the following:

1. Material deterioration caused by age
2. Damage caused by modifications or rough handling
3. Damage caused by inappropriate use not mentioned in the instruction manual
4. Damage caused by unexpected accidents
5. Any damage other than defects in the manufacturing process
6. Damage caused by dust or rust
7. Damage and defects caused by dismantling the product
8. Damage and defects caused by dropping, jolting or other shocks
9. Deterioration or failure of parts due to friction
10. Damage caused by the use of the product in combination with another manufacturer's products

Repairs

- If professional repairs are required, please contact the retailer where you purchased the product or Snow Peak Customer Service.
- When you request repairs, please make sure that the product is dry and clean.
- Please attach a memo or a tag indicating the necessary repairs and write details of how and when the damage occurred.
- Transportation and repair costs will be determined as follows:
 1. Within warranty: The transportation cost (both ways) and repair cost will be covered by Snow Peak.
 2. Outside warranty: The transportation cost (both ways) and repair cost will be covered by the customer.

If you have any questions or concerns, please contact your retailer or Snow Peak customer service.

Snow Peak Customer Service
+1(503)461-0781 (9:00-17:00)
Email: info@snowpeak.com

Snow Peak USA, Inc.
404 NW 23rd Avenue, Portland, Oregon 97210, USA
Tel. +1 (503) 461-0781 / Instagram. @snowpeakusa
Email. info@snowpeak.com / www.snowpeak.com

Cap, bottle body : MADE IN JAPAN
Gasket : MADE IN VIETNAM
Strainer : MADE IN CHINA
This product is quality-controlled and assembled in Japan.